

## ASBESTOS ROOF RESTORATION GUIDE

### Fibro/Asbestos/Super 6 Roofs - Previously Painted

- Do not water blast or scrub
- Prepare the surface with Mouldshield K according to the instructions on the bucket.
- Apply one coat of Shieldseal W @ 110m<sup>2</sup> per 15Lt with an airless spray using a 517 tip size
- Optional—Apply one coat of Fillabond @ 60-65m<sup>2</sup> per 15Lt with an airless spray using a 521-523 tip size (Fillabond is recommended on jobs where the surface is particularly rough and a smooth finish is important)
- Apply two coats of Roofbond @ 75-85m<sup>2</sup> per 15Lt with an airless spray using a 521 tip size
- Apply a final coat of NanoProtect SC-96 @ 150m<sup>2</sup> per 15Lt with an airless spray using a 517 tip size (increases warranty to 12 years with the first 6 covered for fading and gloss retention)

#### Head Office

Building 2, 1075 Beaudesert Rd, (Entry via Kerry Rd, Acacia Ridge), Archerfield, QLD 4108

#### Gold Coast Trade Centre

2/60-64 Kortum drive, Burleigh Heads, QLD 4220

#### Wangard Trade Centre

6/46 Triumph Ave Wangara, Perth WA 60654108