

METAL ROOF RESTORATION GUIDE

DECROMASTIC (METAL TILE) ROOFS

- Prepare the surface with either Mouldshield C or Mouldshield K according to the instructions on the bucket.
- Clean lightly to avoid removing existing stones that would otherwise have good adhesion. Do not use a pressure hose with a turbo head
- Working in small areas at a time (to avoid damage to the Decromastic sheeting and to avoid drying out before application of new stones) apply one coat of Shieldseal W@ 90m² per 15Lt with an airless spray using 517 tip size. Sprinkle new stones onto the wet Shieldseal W.
- Apply a second light coat of Shieldseal W over the area to ensure the adhesion of new stones.
- Optional—Apply one coat of Fillabond@ 60-65m² per 15Lt with an airless spray using a 521-523 tip size (Fillabond is recommended on jobs where the surface is particularly rough and a smooth finish is important)
- Apply two coats of Roofbond@ 75-85m² per 15Lt with an airless spray using a 521 tip size
- Apply a final coat of NanoProtect SC-96 @ 150m² per 15Lt with an airless spray using a 517 tip size (increases warranty to 12 years with the first 6 covered for fading and gloss retention)

Head Office

Building 2, 1075 Beaudesert Rd, (Entry via Kerry Rd, Acacia Ridge), Archerfield, QLD 4108

Gold Coast Trade Centre

2/60-64 Kortum drive, Burleigh Heads, QLD 4220

Wangard Trade Centre

6/46 Triumph Ave Wangara, Perth WA 60654108