

ROOF RESTORATION GUIDE

CONCRETE TILES - UNPAINTED

- Remove and replace broken or cracked tiles and contaminants such as silicone.
- If pointing or bedding needs repairing, replace broken or loose ridge caps and re-bed using a good bedding compound (a 20Kg bag covers approximately 10 ridge caps). Allow 24hrs to dry, then use Roofbond Flexible pointing(10Lt covers approximately 30 ridge caps) to finish off the ridge capping. Allow 24hrs to dry before proceeding with step 3.
- With a 3000 psi water pressure hose clean your roof thoroughly. Once you are sure it's clean, rinse with a normal hose to ensure all fine residue is washed away
- Apply one coat of Shieldseal CT401@ 75-80m per 15Lt with an airless spray using a 517 tip size
- Apply two coats of Roofbond@ 80-90m per 15Lt with an airless spray using a 521 tip size
- Apply a final coat of NanoProtect SC-96@ 150m per 15Lt with an airless spray using a 517 tip size
(Increases warranty to 12 years with the first 6 covered for fading and gloss retention)

Head Office

Building 2, 1075 Beaudesert Rd, (Entry via Kerry Rd, Acacia Ridge), Archerfield, QLD 4108

Gold Coast Trade Centre

2/60-64 Kortum drive, Burleigh Heads, QLD 4220

Wangard Trade Centre

6/46 Triumph Ave Wangara, Perth WA 60654108