

# ROOF RESTORATION GUIDE

## NEW CONCRETE TILES

- Remove and replace broken or cracked tiles and contaminants such as silicone
- If pointing or bedding needs repairing, replace broken or loose ridge caps and re-bed using a 3:1 sand and cement mixture. Allow 24hrs to dry, then apply Roofbond Flexible Pointing as per the instruction on the bucket (10Lt covers approximately 30 ridge caps) to finish off the ridge capping. Allow 24hrs to dry before proceeding to step 3.
- Ensure that your tiles are at least 1 month old before continuing as you need to allow the factory bond breaker coating to wear off.
- Clean very lightly to remove dust, bird droppings and other dirt.
- Apply a light coat of Shieldseal CT401@ 90m<sup>2</sup> per 15Lt with an airless spray using a 517 tip size
- Apply two coats of Roofbond@ 75-85m<sup>2</sup> per 15Lt with an airless spray using a 521 tip size
- Apply a final coat of NanoProtect SC-96@ 150m<sup>2</sup> per 15Lt with an airless spray using a 517 tip size  
(Increases warranty to 12 years with the first 6 covered for fading and gloss retention)

### Head Office

Building 2, 1075 Beaudesert Rd, (Entry via Kerry Rd, Acacia Ridge), Archerfield, QLD 4108

### Gold Coast Trade Centre

2/60-64 Kortum drive, Burleigh Heads, QLD 4220

### Wangard Trade Centre

6/46 Triumph Ave Wangara, Perth WA 60654108